

BEFORE INSTALLATION

- Professional Installation would be highly recommended, please seek assistance at local automotive shop if you have any difficulties in installing.
- Safety comes first ! Do not start to work on any vehicle without protection.
- An assistant would be better assist you in the bumper disassembly work.
- Keep cautions to prevent being scratched when working on any parts from the body of the vehicle.
- Do not touch the bulbs or the wire assembly before they are cooled to avoid the burns.

PRODUCT NUMBER

OEM: 6C3Z-13008-DB, 6C3Z-13008-CB



STEP 1

1. Open the hood. Let`s start from passenger side.

STEP 2



1. Remove (2) 10mm hex bolts on the inner side of headlamp.



2. With socket extension bar, remove (2) 5.5mm hex bolts underneath the headlamp.

STEP 3



1. Grab and pull the headlamp off from the vehicle.



2. Twist light sockets counterclockwise, remove light bulbs from old headlamp.
(Do not touch light bulbs by bare hand.)

STEP 4

1.Insert and twist bulb and socket clockwise to new headlamp.

STEP 5



- 1.Align the mounting tabs with mounting holes on vehicle penal and push to guide the new headlamp in place.
- 2.Reinstall (4) 7/32" hex bolts to secure the new headlamp.

STEP 6

1.Repeat step 2 to step 6 on the passenger side.

WARM TIPS



Before you begin to adjust the light, make sure check the alignment of your lights first. Park the vehicle about 10 to 25 feet from the wall with the lights aimed at the wall. The centerlines of the headlights should not be any higher than 3.5 feet above the ground.

- 1. Find the adjustment screws.
- 2. Adjust the headlights individually.
- 3. Adjust the vertical field.
- 4. Test your results.