

# FM

# FD

## YITAMOTOR FLOOR MATS INSTRUCTION MANUAL



## YITAMOTOR FLOOR MATS INSTRUCTION MANUAL



Follow us on Instagram




## ⚠ WARNING

### READ BEFORE INSTALLING YITAMOTOR FLOOR MATS

Please check the compatibility with the pedals, especially the gas pedal and brake pedal, after installation.

If any interference exists, please remove floor mat immediately and contact us to solve.




☎ 888-717-8084

✉ after-sale.cs@hotmail.com



## MANUAL

1. Remove your old floor mats and clean the carpet.
2. Place "YITAMOTOR Floor Mats" in order. Normally wrong side can not be installed. Reference image shown below:



3. For your safety, please insert the factory carpet hooks or grommets with the secure spots on our mats or using our supplied hardware to secure the mats.
4. Check the pedal interference. Temporary gap between the carpet and mat was normal. They will match each other in few weeks.

