

Bucket integrated installation instruction manual

1. Product overview

No.	NAME	Product length (mm)	tooth (PCS)	pin (PCS)	Bolt + Nut + Flat washer (PCS)
1	Bucket Integrated Digging Teeth -48"	1200	6	6	5
2	Bucket Integrated Digging Teeth -60"	1524	6	6	5
3	Bucket Integrated Digging Teeth -66"	1676	7	7	6
4	Bucket integrated Digging Teeth -72"	1828	7	7	6



2. Product assembly instructions

- 1) Place the bucket motherboard on the corresponding position of the bucket according to the size of the bucket, and fasten it on the excavator with screws and nuts (Note: If there is no reserved hole on the bucket, drill holes on the bucket according to the hole position on the product, and then install the product), as shown in Figure 1 below.
- 2) Place the teeth one by one according to the position of the root on the main board of the product for installation;
- 3) Put the dowel into the hole one by one according to the reserved hole on the tooth. It is necessary to knock the dowel into the hole with a heavy hammer to ensure that the dowel enters the hole completely and the tooth and bucket are installed, as shown in Figure 2 below;
- 4) Assembly is completed.



Figure 1



Figure 2