



INSTRUCTION

RF








LF








screws install
on the car



C	M8	D	8*22
			
16pcs		16pcs	
B	8*30	E	8*2
			
16pcs		16pcs	



H	M6*25	G	M6*25
			
4pcs		4pcs	
			
L/R		L/R	



screws install
on the nerf bar

L		A	8*30	D	8*22
					
4pcs		16pcs		16pcs	
R		E	8*2		
					
4pcs		16pcs			