

BEFORE INSTALLATION

- Professional Installation would be highly recommended, please seek assistance at local automotive shop if you have any difficulties in installing.
- Safety comes first ! Do not start to work on any vehicle without protection.
- An assistant would be better assist you in the bumper disassembly work.
- Keep cautions to prevent being scratched when working on any parts from the body of the vehicle.
- Do not touch the bulbs or the wire assembly before they are cooled to avoid the burns.

PRODUCT NUMBER

OEM Part Number: 22853029, 22853030

Tools Required: 10mm Socket

7mm Socket Ratchet Trim Tool



STEP 1

1. Open the hood.
2. Remove (8) rivets on radiator shield and remove the shield.



STEP 2

1. In front wheel well, remove (2) 7mm hex bolts on bumper cover edge.
 2. Carefully pull bumper edge away from vehicle, beware of hidden clips.
- (Depending on the model of the truck, the front bumper will be attached using rivets, Philips head screw or hex bolts)



STEP 3

1. Remove (3) 10mm bolts secure the headlamp, (2) on the top of headlamp and (1) behind bumper cover.
2. Grab the bottom corner and mounting tab of headlamp and pull the headlamp away from vehicle



STEP 4



1. Disconnect headlight and turn signal light connectors.
2. Twist headlight bulb, signal light and side mark light sockets counterclockwise and remove from old headlamp.
3. 3.Twist signal light and side mark light sockets counterclockwise and remove bulbs from sockets

STEP 5

- 1.Insert bulbs into the new headlamp and sockets.
- 2.Twist sockets and bulbs clockwise to secure on headlamp housing.
- 3.Connect bulbs with the headlamp harness.

STEP 6

- 1.Connect the headlamp connector to vehicle and guide the new headlamp into mounting position.
- 2.Install (3) 10mm hex bolts to secure the new headlamp.


STEP 7

- 1.Repeat step 2 to 6 on the other side

STEP 8

- 1.Reinstall radiator shield and front bumper mounting bolts.

WARM TIPS



Before you begin to adjust the light, make sure check the alignment of your lights first. Park the vehicle about 10 to 25 feet from the wall with the lights aimed at the wall. The centerlines of the headlights should not be any higher than 3.5 feet above the ground.

1. Find the adjustment screws.
2. Adjust the headlights individually.
3. Adjust the vertical field.
4. Test your results.