



FEATURE

High quality injection molding fender flares

Made from light weight impact resistance Polypropylene, non-cracking, non-warping, 100% UV-resistant.

Factory holes -

some models may require drilling

Injection molded smooth(Not Textured) matt black finish

for paintable

Professional installation is always recommended

Step 1 Before Installation

A.Fit: Fit of the flare to vehicle should be confirmed. Some filing, sanding, or cutting may be adopted for proper fit if necessary.

B.Painting: (optional) if paint is desired it must be done prior of installing flares on vehicle. Clean outer surface with a good grade degreaser.

C.Metal protection: Rust resistance paint of all exposed fasteners and bare metal should be done BEFOR installin-g flares. Undercoating the inner fender wells should be done AFTER flare attachments have been completed.

D.Flares may interfere with existing decals on vehicle. If you wish. Remove decals prior to installation of flares.

2019+ Chevrolet Pocket Fender Flares

Set of 4

TOOLS FOR EASY INSTALLATION:

- Utility Knife
- #2 Phillips Driver
- Socket Wrench
- 10mm Socket
- T15 Torx Bit
- Awl or Similar Pointed Tool
- Grease Pencil
- Pliers


If your flares already have the edge trim installed, skip to Front Flare Installation Step 1.

STEP 2 - EDGE TRIM INSTALLATION

A) Peel two to three inches of red vinyl backing away from Edge Trim (GP1-0025) tape. Applying the adhesive side of the edge trim to the inner side of the flare, affix the edge trim to the top edge of the flare (the portion that comes in contact with the vehicle).

B) Press edge trim into place along the top edge of the flare in one-foot increments, pulling red vinyl backing free as you continue to work your way around the top edge of the flare.

C)FRONT FLARES ONLY: The edge trim must be cut to prevent bunching and stretching at the forward end of the part where the flare goes along the headlight.




Pocket Hardware Installation Procedures:



Put a Washer (WA1-0012) on each Bolt (SW1-0067).



Put each Bolt/Washer combination through a pocket hole in the flare, Bolt head and Washer on the outside.




Place a Nut (NU1-0019) over the end of each Bolt and tighten, using a 1/2" wrench for the Nut and the supplied Torx Bit (SW1-0052) for the Bolt. Repeat for remaining pockets.


Front Flare Installation Procedures (Passenger's Side):




Locate the factory installed mud flap on the passenger side front wheel well.



Remove (3) factory installed T15 screws, and (1) factory installed 10mm bolt. Note that two T15 screws labeled (A) and (B) above will be re-used to install the flare. You may discard (C) and (D).




Firmly pull the mud flap away from vehicle in order to disengage the factory retaining clip, and remove mudflap from vehicle. If necessary, pliers may be needed to squeeze clip from behind.



Hold flare to vehicle and note the approximate hole locations in the flare.



Use a grease pencil to mark the two locations of the holes indicated with the circles in Step 8. Remove flare from vehicle.




Install supplied Tab (MT1-0034) over the rear location marked in Step 9. Install a Clip (CL1-0009) as indicated on top of the protective film.




Install supplied Tab (MT1-0017) over the front location marked in Step 9. Install a clip assembly as indicated, on top of the Tab. See Step 13 for detail of clip attachment.



Hold flare to vehicle and re-install (3) factory screws (removed in Step 7) with a T15 bit. **Do not tighten**



NOTE: STEPS 11-13 APPLY TO 2019-2022 LTD ONLY. Assemble Clip CL1-008 with CL1-0010 as indicated in the above diagram. Insert tab of CL1-0008 through slot in CL1-0010.



Press down on CL1-0008 as indicated until an audible "snap" is heard. **NOTE:** This may require pliers.



Re-install (2) factory screws (removed in Step 5) with a T15 bit. **Do not tighten**

Included in Hardware Kit:

- | | | | | | | |
|---|--|---|--|--|---|--|
| 1. CL1-0009, Long "U" Clip, Magni 565
12 pcs | 2. SW1-0058, #10 x 5/8" Phillips SS Truss Screw,
12 pcs | 3. MT1-0034, 1" x 1.5" x .06" Blk 3M Foam Tab,
12 pcs | 4. SW1-0049, 10 x 3/4" Phillips Tapping Screw,
2 pcs (2019-22 LTD) | 5. MT1-0017, 1" x 1.5" x .002" Clear Tab,
2 pcs (2019-22 LTD) | 6. CL1-0008, 1" Dacromet Inner Clip,
2 pcs (2019-22 LTD) | 7. CL1-0010, Dacromet Outer Clip,
2 pcs (2019-22 LTD) |
| 8. ET1-0002, Edge Trim Tool,
1 pc | 9. GP1-0025, Edge Trim
360 inches | 10. SW1-0067, 5/16 x 18 x 3/8" SS Torx Screw,
36 pcs (Pocket Style Only) | 11. WA1-0012, .320 x .700 x .03 SS Washer,
36 pcs (Pocket Style Only) | 12. NU1-0019, 5/16-18 Jam Fin. Nylock Nut,
36 pcs (Pocket Style Only) | 13. SW1-0052, T-45 Torx Bit,
1 pc (Pocket Style Only) | 122441, Lever Clip,
2 pcs. (2022 +) |



Install (1) supplied Phillips head screw (SW1-0058) at rear Clip location. **Do not tighten** (If needed use an awl to align flare mounting holes.)



FOR 2019-2022 LTD ONLY: Install (1) supplied Phillips head screw (SW1-0049) at front Clip location. **Do not tighten** (If needed use an awl to align flare mounting holes.)



FOR 2022+ ONLY: Remove (1) T-15 torx screw and install (1) 122441 Clip. Reinstall screw and tighten.




Press flare firmly against body and tighten all screws.



Completed front flare installation.


Rear Flare Installation Procedures (Passenger's Side)



Locate the mud flap in front of the rear wheel. Remove (5) factory installed T15 screws. Note that T15 screws labeled (A) and (C) will be re-used to install the flare. You may discard (B), (D), and (E).




Firmly pull the mud flap away from vehicle in order to disengage the factory retaining clip, and remove mudflap from vehicle. If necessary, pliers may be needed to squeeze clip from behind.



Locate the mud flap behind the rear wheel. Remove (2) factory installed T15 screws. NOTE: T15 screw labeled (B) will be re-used.



Hold flare to vehicle and note the approximate hole locations in the flare.



Use a grease pencil to mark the five locations of the holes indicated by the circles in Step 24. Remove flare from vehicle.




Install supplied Tab (MT1-0034) at each location marked in Step 25.




Install a supplied Clip (CL1-0009) over each Tab (MT1-0034).



Re-install (3) factory T15 screws as indicated above. **Do not tighten**



Hold flare to vehicle and install (5) supplied Phillips head screws (SW1-0058) at each Clip location. **Do not tighten** (If needed use an awl to align flare mounting holes.)



Press flare firmly against body and tighten all screws.



Completed rear flare installation.

Edge Trim Tool Procedures:



Using supplied Edge Trim Tool (ET1-0002), seat edge trim against vehicle by hooking curved end under edge trim at one end of flare. Next, slide around outer edge of flare to the other end.



Using flat end of supplied Edge Trim Tool (ET1-0002), seat edge trim against flare by inserting straight end between edge trim and flare at one end. Next, slide around entire edge to the other end.