

## BEFORE INSTALLATION


- Professional Installation would be highly recommended, please seek assistance at local automotive shop if you have any difficulties in installing.
- Safety comes first ! Do not start to work on any vehicle without protection.
- An assistant would be better assist you in the bumper disassembly work.
- Keep cautions to prevent being scratched when working on any parts from the body of the vehicle.
- Do not touch the bulbs or the wire assembly before they are cooled to avoid the burns.

## PRODUCT NUMBER

OEM Part Number: 3L3Z 13008 DA, 3L3Z 13008 CA



## STEP 1




1. Open the hood.
2. Pull (2) metal clips rearward and up to release the headlamp.
3. Pull the headlamp forward.
4. Disconnect headlight connector.

## STEP 2


1. Twist headlight bulb retainer counterclockwise and remove from the old headlamp.
2. Remove headlight bulb from the old headlamp.
3. Remove the old headlamp from vehicle.

## STEP 3




1. Remove (1) screw securing the signal parking lamp.
2. Disengage clips securing the signal parking lamp.
3. Twist signal parking light socket counterclockwise and remove from the old signal parking lamp.
4. Remove the old signal parking lamp from vehicle.

## STEP 4



1. Insert and lock signal parking light socket into the new signal parking lamp.
2. Align top and bottom ribs of signal parking lamp with corresponding slots on front of vehicle.
3. Engage clips to secure signal parking lamp to vehicle.
4. Install (1) screw on the signal parking lamp.

## STEP 5



1. Insert headlight bulb into the new headlamp and secure with bulb retainer.
2. Connect headlight connector.
3. Insert the headlamp into the vehicle, guiding the alignment pins insert into the correct guide ribs.
4. Push down (2) clips to lock the headlamp into place.
5. Repeat above steps on the other side.

## WARM TIPS

### High / Low Beam Adjustment Screws



Before you begin to adjust the light, make sure check the alignment of your lights first. Park the vehicle about 10 to 25 feet from the wall with the lights aimed at the wall. The centerlines of the headlights should not be any higher than 3.5 feet above the ground.

1. Find the adjustment screws.
2. Adjust the headlights individually.
3. Adjust the vertical field.
4. Test your results.